


User Guide

EXTECH[®]
INSTRUMENTS

A FLIR COMPANY

Heavy Duty Vibration Meter

Model 407860




Distributed by MicroDAQ.com, Ltd
www.MicroDAQ.com
(603) 746-5524

Introduction


Congratulations on your purchase of the Extech 407860 Vibration Meter. The Model 407860 measures vibration levels in industrial machinery. Misalignment, poor balancing, structural compromises, and other factors can cause unwanted vibration increases. The Model 407860 has a frequency sensitivity that meets ISO-2954 and offers Displacement, Velocity and Acceleration features. This meter is shipped fully tested and calibrated and, with proper use, will provide years of reliable service.

Meter Description

1. Probe connector
2. RS-232 Connector
3. LCD Display
4. Function switches and pushbuttons
5. Probe
6. Magnetic base
7. Protective rubber meter jacket
8. Battery compartment (on rear)




Meter LCD Display




Meter Operation

Connecting the Probe


1. Note that this meter accepts only the supplied vibration probe.
2. Plug the BNC connector end of the probe cable onto the BNC connector at the top of the meter.
3. The probe can then be connected to the tested machinery in three ways.
 - a. Attach the magnetic end of the probe to a ferrous material on the equipment under test as shown in the accompanying diagram.



- b. Manually hold the probe in place against the equipment under test as shown.



- c. Unscrew the magnet from the probe end (as shown in the diagram) and use the threaded mount to connect to a screw, bolt, or stud on the equipment under test.



POWER button and Auto Power OFF feature

1. Press the **POWER** button to turn the meter ON. If the meter does not turn on, check the 9V battery.
2. To turn the meter off, press and hold the **POWER** button until the meter beeps.
3. The meter is equipped with an Automatic Power OFF utility that conserves battery life. If the meter is left inactive for 10 minutes it will automatically turn off.
Note: Automatic Power OFF utility is disabled in the RECORD mode.

FUNCTION button

Press the **FUNCTION** button to select RMS, PEAK or MAX-HOLD.

1. **RMS** - Typical selection for vibration measurements
2. **PEAK** – For measurement of the peak value. Not available in the Displacement mode.
3. **MAX_HOLD** – Holds and displays the maximum value. The display will update only when a new maximum is measured. Not available in the Displacement mode.

UNIT button

Press this button to select the measurement units desired.

Press and hold this button for > 5 seconds to switch from metric to imperial units.

| Measurement | Metric Units | Imperial Units |
|--------------|----------------------|-------------------|
| Acceleration | m/s ² , G | Ft/s ² |
| Velocity | mm/s, cm/s | Inch/s |
| Displacement | mm | inch |

HOLD button

Press this button to freeze the measured value in the display. HOLD will appear in the display. Press the button again to return to normal operation.

REC button

Use this feature to record the maximum and minimum measured values.

1. Press the **REC** button to begin recording. The REC symbol will appear on the display.
2. Press the **REC** button again to display the MAX recorded value. Both the REC and MAX symbols will appear on the display.
3. Press the **REC** button again to display the MIN recorded value. Both the REC and MIN symbols will appear on the display.
4. Press and hold the **REC** button for >2 seconds to exit the REC mode.

ZERO Adjustment

The meter may not indicate zero (or may indicate within a few digits of zero) with no signal applied to the meter (no vibration). Although this is usually not a problem, this procedure will bring the meter within a few digits of zero and improve measurement precision.

1. Connect the vibration sensor to the meter.
2. Turn the meter on and set the function to ACC and RMS.
3. Make sure the vibration sensor is perfectly still (no vibration).
4. Press and hold the **HOLD** button for > 5 seconds to allow the display to reach the zero value.

Datalogging

The internal datalogger memory can hold up to 500 readings. Readings can be logged manually, with a button press, or automatically at a programmed sample rate.

Sample Rate

The sample rate can be set to 0 (manual), 1, 2, 5, 10, 30, 60, 600, 1800 or 3600 seconds.

1. With the meter OFF, Press and hold the **HOLD** and **REC** buttons.
2. Press the **POWER** button.
3. When the display shows the sample rate, release the **HOLD & REC** buttons.
4. Use the **UNIT** button to select the desired sample rate.
5. Press the **REC** button to save the selection. The meter will sound three tones indicating that the sample rate was successfully stored.
6. Follow the Auto or Manual Datalogging procedures in the next section.
7. To return to normal operation, simply cycle the meter's power.

Auto Data Logging

1. Set the desired sample rate as described (do not select '0').
2. Turn the meter off and back on.
3. Press the **REC** button to enter the datalogging function. The **REC** symbol will appear in the display (upper left-hand corner).
4. Press the **LOGGER** button to start logging data. The display will briefly indicate the sample rate and the **REC** indicator will flash
5. An audible tone will sound each time a reading is stored.
6. Press the **LOGGER** button for to pause/resume datalogging.
7. Press and hold the **REC** button > 2 seconds to exit the datalogging mode.

Manual Data Logging

1. Set the sample rate to '0' as described earlier.
2. Turn the meter off and back on.
3. Press the **REC** to enter the datalogging function. The **REC** symbol will appear in the display flashing.
4. Press the **LOGGER** button. The display will briefly indicate the '0' sample rate.
5. Press **LOGGER** again to log one data point. The **REC** indicator will flash and an audible tone will sound. Repeat this step to store the desired number of readings.
6. Press and hold the **REC** button > 2 seconds to exit the datalogging mode.

Clearing Memory

1. With the meter OFF, Press and hold the **HOLD** and **REC** buttons.
2. Press the **POWER** button.
3. When the display shows the sample rate, release the **HOLD** and **REC** buttons.
4. Press and hold the **REC** button for > 5 seconds. The display will indicate 0 when the memory is clear.
5. Cycle the meter power to return to normal operation.

Memory Full Indication

The meter produces a continuous tone when the internal memory has been filled to capacity (500 readings). The data can be viewed, cleared, or downloaded to a PC.

Viewing Stored Data

1. With the meter OFF, Press and hold the **HOLD** and **REC** buttons.
2. Press the **POWER** button.
3. When the display indicates the existing sample rate, release the **HOLD** and **REC** buttons.
4. The **HOLD** and the **FUNCTION** buttons are used to scroll through the stored data. When either button is pressed, the data reference number will briefly appear and then the reading for the given memory location will be displayed. The **HOLD** button increments the data location number and the **FUNCTION** button decrements the data location number.

PC Interface

The meter is equipped with an RS-232 serial data port (located at the top of the meter next to the probe input jack). This interface was designed to operate with the 407001A Extech software package which includes two programs and the required meter to pc cable.

1. **407001A** - Extech Data Acquisition Software: This software allows the user the meter to a PC and view readings in real-time as they are taken (this software does not download the contents of the meter's memory to the PC)
2. **DL2005** - Datalogger Download Software: This software allows the user to download the contents of the meter's memory to the PC

Download Stored Data to PC (requires DL2005 software)

The **SEND** button is used to send the contents of the meter's internal datalogger memory to the PC via the optional DL2005 software.

1. Connect the RS-232 cable to the PC
2. Install and run the DL2005 datalogging software.
3. With **HOLD** and **REC** not selected press and hold the **SEND** button for > 2 seconds. "232" (flashing) will appear in the display.
4. Press the **SEND** button again and the data will be sent to the meter's RS-232 port and onto the connected PC.
5. Press the **ESC** button to return to normal operation.

Battery Replacement

When the 9V battery weakens, the  indicator appears on the LCD. Follow these steps to replace the battery:

1. Turn the meter OFF.
2. Remove the probe and the RS-232 cable from the meter.
3. Remove the protective rubber jacket that encases the meter by stretching it over the bottom of the meter.
4. Open the battery compartment (located on the lower back of the meter) with a flat head screwdriver or coin.
5. Replace the 9V battery, replace the compartment cover, and affix the rubber jacket.

You, as the end user, are legally bound (**Battery ordinance**) to return all used batteries and accumulators; **disposal in the household garbage is prohibited!**



You can hand over your used batteries / accumulators at collection points in your community or wherever batteries / accumulators are sold!

Disposal: Follow the valid legal stipulations in respect of the disposal of the device at the end of its lifecycle

Specifications

General Specifications

| | |
|-------------------------|---|
| Display | 3-1/2 digit LCD with bar-graph |
| Frequency range | 10Hz to 1KHz (frequency sensitivity meets ISO-2954) |
| Sampling time | One (1) second approx. |
| Data output | Isolated serial RS-232 PC Interface |
| Data Hold | Freezes displayed reading |
| Min/Max Memory | Meter stores highest and lowest readings for later recall |
| Data Logger | Store up to 500 readings |
| Data logger Sample Time | 0 (manual), 1, 2, 10, 30, 60, 600, 1800 and 3600 sec. |
| Pickup thread size | 10-32 UNF |
| Auto Power OFF | Meter automatically shuts off after 10 minutes of inactivity |
| Low battery indication | Battery symbol appears on the LCD |
| Power supply | 9V Battery |
| Power consumption | 8mA DC approx. |
| Operating Temperature | 0 to 50°C (32 to 122°F) |
| Operating Humidity | Less than 80% RH |
| Dimensions | Meter: 180 x 72 x 32mm (7.1 x 2.8 x 1.3") Probe: 18mm (0.75") diameter x 40mm (1.6") |
| Weight | Meter: Approx. 230g (0.5 lbs) Probe with magnetic base: 110g (0.24 lbs) |

Functions, Units, Ranges, and Accuracy

| Acceleration (RMS or Peak) | Unit | Range | Accuracy (% of reading) |
|--|------------------------------------|------------------------------|-------------------------|
| | m/s ² | 0.5 to 199.9m/s ² | ±(5% + 2 digits) |
| | G | 0.05 to 20.39G | |
| | ft/s ² | 2 to 656ft/s ² | |
| Calibration point: 50 ft/s ² @ 160Hz | | | |
| Velocity (RMS or Peak) | mm/s | 0.5 to 199.9mm/s | ±(5% + 2 digits) |
| | cm/s | 0.05 to 19.99cm/s | |
| | in/s | 0.02 to 7.87in/s | |
| Calibration point: 50mm/s @ 160Hz | | | |
| Displacement (peak to peak) | mm | 1.999mm | ±(5% + 2 digits) |
| | inch | 0.078in | |
| | Calibration point: 0.141mm @ 160Hz | | |
| Note: Accuracy stated from 80 to 160Hz @ 23 ± 5°C | | | |

Copyright © 2007 Extech Instruments Corporation

All rights reserved including the right of reproduction in whole or in part in any form.

Distributed by MicroDAQ.com, Ltd
www.MicroDAQ.com
(603) 746-5524

Appendix A: Machinery Classification

When evaluating machinery and equipment it is useful to know their classification range and group type. There are four machine groups and classification ranges recognized internationally (ISO 2372 and VDI 2056). The limits for vibration severity (mm/s) are shown in the Tables below:

GROUP K – Small Machinery up to 15KW (for example, production motors)

| Testing Status | Vibration Severity (mm/s) |
|-----------------------|----------------------------------|
| Good | 0 to 0.71 |
| Acceptable | 0.72 to 1.80 |
| Permissible | 1.81 to 4.5 |
| Dangerous | Greater than 4.5 |

GROUP M – Medium-sized Machinery up to 75KW (for example, electrical motors without special foundations)

| Testing Status | Vibration Severity (mm/s) |
|-----------------------|----------------------------------|
| Good | 0.00 to 1.12 |
| Acceptable | 1.13 to 2.80 |
| Permissible | 2.81 to 7.10 |
| Dangerous | Greater than 7.10 |

GROUP G – Large Machinery on Heavy Foundations

| Testing Status | Vibration Severity (mm/s) |
|-----------------------|----------------------------------|
| Good | 0.00 to 1.80 |
| Acceptable | 1.81 to 4.50 |
| Permissible | 4.51 to 11.20 |
| Dangerous | Greater than 11.20 |

GROUP T – Large Turbo Machinery on Special Foundations

| Testing Status | Vibration Severity (mm/s) |
|-----------------------|----------------------------------|
| Good | 0 to 2.80 |
| Acceptable | 2.81 to 7.10 |
| Permissible | 7.11 to 18.00 |
| Dangerous | Greater than 18.00 |

Appendix B: Relative Sensitivity Table (ISO 2954)

| Frequency (Hz) | Relative sensitivity | | |
|----------------|----------------------|---------------|---------------|
| | Normal value | Minimum value | Maximum value |
| 10 | 1.0 | 0.8 | 1.1 |
| 20 | 1.0 | 0.9 | 1.1 |
| 40 | 1.0 | 0.9 | 1.1 |
| 80 | 1.0 | 1.0 | 1.0 |
| 160 | 1.0 | 0.9 | 1.1 |
| 500 | 1.0 | 0.9 | 1.1 |
| 1000 | 1.0 | 0.8 | 1.1 |

Appendix C: Glossary

Vibration: Vibration is an oscillation or repetitive motion of an object around an equilibrium position.

Displacement: Displacement is the peak-to-peak distance from a reference position, or equilibrium point, of an object under test.

Peak to Peak Amplitude: Peak –to-peak amplitude is the displacement of an object (see above). It can be thought of as the distance from the maximum positive deviation point to the maximum negative deviation point with respect to an object's equilibrium position.

Velocity: Velocity is the *rate of change* of displacement. Velocity is measured in inches/second (mm/second) units.

Acceleration: Acceleration is the *rate of change* of velocity. Units of measure for Acceleration is feet per second squared (meters per second squared)

Peak Amplitude: Maximum deviation of an object from its equilibrium position.

RMS: Root Mean Square Amplitude (RMS) is the square root of the average of the squared values of a waveform. The RMS amplitude of vibration is 0.707 times the peak amplitude value The RMS value of a vibration signal is an important measure of its amplitude.