



Finishing Up - Additional Help

You have now installed your Keyspan USB Server hardware and software as well as learned how to use your first USB device via your USB Server. The instructions provided here are intended to cover the basic use of the Keyspan USB Server using our default settings. While our default settings are suitable for most uses, you may want to configure the USB Server to use different settings depending on your needs. Please refer to our electronic user's manual for more information about changing your settings.



Notes About Networks And Multiple Users

By default, the Keyspan USB Server can be accessible to your computer via a LAN (local area network) or Wireless LAN. If you want additional users to connect to your USB Server, you will need to install the Keyspan USB Server software on each 'client' computer.

Notes About Firewalls

If you have installed a software or hardware firewall, you may need to configure it to allow access to your USB Server. Please refer to our electronic user's manual for further details.

Need help with this Keyspan product? Please contact us at:
web: www.keyspan.com/support/
fax: +1 510 222 0323
telephone: +1 510 222 8802



(Rev XIS-US4A.A0.0404)



Finishing Up - Additional Help

You have now installed your Keyspan USB Server hardware and software as well as learned how to use your first USB device via your USB Server. The instructions provided here are intended to cover the basic use of the Keyspan USB Server using our default settings. While our default settings are suitable for most uses, you may want to configure the USB Server to use different settings depending on your needs. Please refer to our electronic user's manual for more information about changing your settings.



Notes About Networks And Multiple Users

By default, the Keyspan USB Server can be accessible to your computer via a LAN (local area network) or Wireless LAN. If you want additional users to connect to your USB Server, you will need to install the Keyspan USB Server software on each 'client' computer.

Notes About Firewalls

If you have installed a software or hardware firewall, you may need to configure it to allow access to your USB Server. Please refer to our electronic user's manual for further details.

Need help with this Keyspan product? Please contact us at:
web: www.keyspan.com/support/
fax: +1 510 222 0323
telephone: +1 510 222 8802



(Rev XIS-US4A.A0.0404)

Keyspan USB Server QuickStart

Thank you for purchasing the Keyspan USB Server. This QuickStart guide is intended to quickly get you up and running with your new Keyspan USB Server. For more detailed instructions, please refer to the electronic documentation on your Keyspan CD.



Hardware Installation

Connect your Keyspan USB Server to your network using a RJ45 Ethernet cable. Then connect the included power supply to your Keyspan USB Server. You should now see lights on your Keyspan USB Server. When the left-most (green) SYSTEM light starts blinking slowly (once every 3 seconds), proceed to the next step.

TROUBLESHOOTING: If the do not see the left-most (green) SYSTEM light blinking slowly, please read the detailed troubleshooting instructions located in the USB Server's electronic user's manual. This manual can be found on your Keyspan CD and web site.



Software Installation

Turn your computer ON. When your computer starts up, place the Keyspan USB Server CD into the CD-ROM drive.

Keyspan USB Server QuickStart

Thank you for purchasing the Keyspan USB Server. This QuickStart guide is intended to quickly get you up and running with your new Keyspan USB Server. For more detailed instructions, please refer to the electronic documentation on your Keyspan CD.



Hardware Installation

Connect your Keyspan USB Server to your network using a RJ45 Ethernet cable. Then connect the included power supply to your Keyspan USB Server. You should now see lights on your Keyspan USB Server. When the left-most (green) SYSTEM light starts blinking slowly (once every 3 seconds), proceed to the next step.

TROUBLESHOOTING: If the do not see the left-most (green) SYSTEM light blinking slowly, please read the detailed troubleshooting instructions located in the USB Server's electronic user's manual. This manual can be found on your Keyspan CD and web site.



Software Installation

Turn your computer ON. When your computer starts up, place the Keyspan USB Server CD into the CD-ROM drive.

MACINTOSH:

When the CD icon appears on your desktop, double click on its icon to display its contents. Locate the Keyspan USB Server Installer icon and double click to start the installation process. Follow the instructions on-screen.

WINDOWS:

Windows will automatically open the Keyspan CD Browser window. Using the on-screen menus, locate the Keyspan USB Server Installer selection and click it to start the installation process. Follow the instructions on-screen.

WINDOWS Tech Note. During and/or after the software installation, the Windows New Hardware Wizard may ask you to install software several times. Select 'Install the software automatically'. You may also get an additional prompt regarding logo testing, click 'Continue Anyway' to proceed. Please note that you may need to repeat this process up to 3 times.

Once the Keyspan installer completes, it will automatically launch the Keyspan USB Server application. Once this window opens, proceed to the next step.



Using Your First USB Device Via The Keyspan USB Server

Physically connect your first USB device (ie printer, scanner, etc) to any USB port on the USB Server. Then open the Keyspan USB Server application.

MACINTOSH:

The Keyspan USB Server application is located in your Applications folder.

MACINTOSH:

When the CD icon appears on your desktop, double click on its icon to display its contents. Locate the Keyspan USB Server Installer icon and double click to start the installation process. Follow the instructions on-screen.

WINDOWS:

Windows will automatically open the Keyspan CD Browser window. Using the on-screen menus, locate the Keyspan USB Server Installer selection and click it to start the installation process. Follow the instructions on-screen.

WINDOWS Tech Note. During and/or after the software installation, the Windows New Hardware Wizard may ask you to install software several times. Select 'Install the software automatically'. You may also get an additional prompt regarding logo testing, click 'Continue Anyway' to proceed. Please note that you may need to repeat this process up to 3 times.

Once the Keyspan installer completes, it will automatically launch the Keyspan USB Server application. Once this window opens, proceed to the next step.



Using Your First USB Device Via The Keyspan USB Server

Physically connect your first USB device (ie printer, scanner, etc) to any USB port on the USB Server. Then open the Keyspan USB Server application.

MACINTOSH:

The Keyspan USB Server application is located in your Applications folder.

WINDOWS:

The Keyspan USB Server application is located in your START menu -> PROGRAMS -> KEYSpan USB SERVER.

Once the Keyspan USB Server application is open, click on the **USB Devices** tab. You will notice your USB device located under the **Other Devices** heading.

To use your USB device, select your device by clicking on its name and then click the **Connect** button at the bottom of the USB Devices tab. This will move your USB device to the **My Devices** heading. You can now use your device as if it is directly connected to your computer.

When you are finished using your USB device, select your USB device and click the **Disconnect** button at the bottom of the USB Devices tab. This will return your USB devices to **Other Devices** and make your device available to other USB Server users. To use additional USB devices, repeat this step.

TROUBLESHOOTING: If you do not see your USB device in the Keyspan USB Server application, please read the detailed troubleshooting instructions located in the USB Server's electronic user's manual. This manual can be found on the Keyspan CD and web site.

WINDOWS:

The Keyspan USB Server application is located in your START menu -> PROGRAMS -> KEYSpan USB SERVER.

Once the Keyspan USB Server application is open, click on the **USB Devices** tab. You will notice your USB device located under the **Other Devices** heading.

To use your USB device, select your device by clicking on its name and then click the **Connect** button at the bottom of the USB Devices tab. This will move your USB device to the **My Devices** heading. You can now use your device as if it is directly connected to your computer.

When you are finished using your USB device, select your USB device and click the **Disconnect** button at the bottom of the USB Devices tab. This will return your USB devices to **Other Devices** and make your device available to other USB Server users. To use additional USB devices, repeat this step.

TROUBLESHOOTING: If you do not see your USB device in the Keyspan USB Server application, please read the detailed troubleshooting instructions located in the USB Server's electronic user's manual. This manual can be found on the Keyspan CD and web site.