

California Department of Public Health

Vaccines for Children Program

LogTag TRE30-7R Configuration when using LogTag Wizard

Push Button Start

Record a reading every **15** minutes

Begin recording after a delay of **0** minutes

Configure Alarms

REFRIGERATOR	Upper Alarm Setting	Lower Alarm Setting
Fahrenheit	above/equal to 46.1 degrees Fahrenheit	below/equal to 34.9 degrees Fahrenheit
Celsius	above/equal to 8.1 degrees Celsius	below/equal to 1.9 degrees Celsius

Upper temperature parameters

- ✓ Trigger alarm when readings above/equal (see table above)
- ✓ After **2** Consecutive violation readings (30 minutes)

Lower temperature parameters

- ✓ Trigger alarm when readings below/equal (see table above)
- Unchecked box for no violation readings (None)

No Password

Advanced Options

- ✓ Alarm remains on even if readings return to non-violation range

Temperature display unit in Fahrenheit or Celsius, depending on clinic staff preference

- ✓ Switch off display after 30 seconds (Power save)
- ✓ Allow logging stop with STOP button
- ✓ Show total summary days collected