

EL-USB-CO

Carbon Monoxide (CO) Data Logger with USB Interface

This data logger measures and stores up to 32,510 Carbon Monoxide (CO) readings over a 0 to 1000 ppm measurement range and -10 to +40°C (14 to +104°F) operating temperature range. The user can easily set up the logging rate and start time, and download the stored data by plugging the module straight into a PC's USB port and running the purpose designed software under Windows 98, 2000 or XP. The data can then be graphed, printed and exported to other applications. The data logger is supplied complete with a long-life lithium battery. Data is stored in non-volatile memory and is not lost when the battery is empty. A bright red LED will flash and a buzzer can sound when a preset warning level has been exceeded.

FEATURES

- 0 to 1000 ppm CO measurement range
- Stores up to 32,510 Measurements
- User-Programmable Warning Threshold with Bright Visual and Audible Warning
- USB Interface for Set-up and Data Download
- Expected sensor life: 4 years
- Replaceable Internal Lithium Battery



WINDOWS CONTROL SOFTWARE

Easy to install and use, the control software runs under Windows 98, 2000 and XP (Home and Professional Editions). It allows the user to set up and download any EL-USB-CO. The latest version of the control software may be downloaded from www.lascarelectronics.com.

DATA LOGGER SET-UPS

- Logger Name
- Logging Rate (10s, 30s, 1m, 5m)
- Warning Threshold
- Start Date and Start Time

ORDERING INFORMATION

| | |
|---|---------------------------|
| Standard Data Logger (Data Logger, Software on CD, Battery) | Stock Number EL-USB-CO |
| Replacement Battery | BAT 3V6 |

IMPORTANT SAFETY WARNING:

DO NOT ATTEMPT TO USE THE EL-USB-CO WITHOUT READING AND UNDERSTANDING THE DOCUMENTATION. CARBON MONOXIDE MONITORING IS A COMPLEX PROCEDURE. IF THERE IS ANY DOUBT AS TO THE SAFETY OR APPLICATION - STOP! CONSULT A QUALIFIED EXPERT.

The EL-USB-CO is a professional measuring instrument, designed to record Carbon Monoxide (CO) gas levels for later analysis. It is not an alarm/safety/warning device and should not be used in this capacity for the following reasons:

- 1. The lights and sound emitted by the EL-USB-CO to indicate a high level of CO do not provide adequate warning to those in the surrounding area that a high level of CO has been recorded.**
- 2. The battery life of the EL-USB-CO during audible and visual indication of a high level of CO will rapidly diminish and will therefore only be active for a short period of time.**
- 3. The EL-USB-CO takes a sample reading at intervals as set by the user for recording/monitoring/analysis purposes. Dangerous levels of CO will not register with the device until a sample reading is taken.**
- 4. Due to the limitations of the device as a professional instrument, it is left to the user to set the light and sound alarms indicating the presence of company. Therefore the instrument can be set up to provide NO form of warning.**

Carbon Monoxide is poisonous. It is clear, colorless gas that has no smell or taste and can be lethal even in very low concentrations. It can injure or kill people and animals who are not adequately warned of its presence.

In areas where the safety of humans and animals is a concern we insist that a domestic or industrial CO detector/alarm, designed to a nationally approved quality standard, with features such as a high decibel alarm or siren and a clear visual warning, specifically designed to provide adequate warning of dangerous CO levels, be installed, used and maintained.

SPECIFICATIONS

| Specification | Min. | Typ. | Max. | Unit |
|---|-----------|------|------------|---------------------|
| Measurement range | 0 | | 1000 | ppm CO |
| Internal resolution | | 0.5 | | ppm CO |
| Accuracy (error) | | ±6 | | % of reading |
| Repeatability | | ±2 | | % of reading |
| Decay of reading over time | | | 5 | % of reading / year |
| Response time (to reach 90%) | | 1 | | minute |
| Logging rate | every 10s | | every 12hr | - |
| Operating temperature range (15-90 %RH, non-condensing) | -10 (14) | | +40 (104) | °C (°F) |
| Operating pressure range | 900 | | 1100 | mbar |
| 1/2AA 3.6V Lithium Battery Life* | | | 3 | month |

* with battery supplied, 10 minute logging rate, 25°C ambient temperature, audible warning disabled, reading <10 ppm CO

LED FLASHING MODES

EL-USB-CO features a red and a green LED.

The LEDs on an EL-USB-CO will flash in one of the following ways, assuming latching of the warning threshold has been turned off in the EL-WIN-USB control software.

- Green single flash, every 30 seconds Logger primed and ready to start.
- Green single flash, every 10 seconds Logging in progress, last stored value OK
- Red single flash, every 10 seconds Logging in progress, the last stored reading is equal to or exceeds the warning threshold (If latching is turned on, then a stored value is equal to or exceeds the warning threshold) (will flash once every second when audible warning is enabled)
- Green single flash, every 20 seconds Low battery, logging in progress, the last stored value OK
- Green double flash, every 20 seconds Logger is full, last stored value OK
- Red/Green single flash, every 20 seconds, alarm latching turned on Logger is full, last stored value is equal to or exceeds the warning threshold (will flash once every second when audible warning is enabled)
- No LEDs flash Battery inserted, but no logging exercise started
or
Battery dead.

By default latching is disabled. The red LED will not flash after the logged voltage has returned to normal. Instead, the green LED will flash.

Latching can be turned on via the control software. The red LED will then continue to flash, even after the logged CO value has returned to normal. The red LED will effectively have latched into its warning condition. This feature ensures that the user is notified that the warning threshold has been exceeded, without the need to download the data from the logger.

AUDIBLE WARNING

The audible warning will sound once per second when the warning threshold has been exceeded. To disable the warning, remove the cap from the front of the data logger.

The audible warning will sound once every 60 seconds when there is a low battery condition. This indicates that the battery must be replaced.

BATTERY REPLACEMENT

- We recommend that you replace the battery every 3 months, or prior to logging critical data.
- The EL-USB-CO does not lose its stored readings when the battery is discharged or when the battery is replaced; the data logging process will however be stopped and cannot be re-started until the battery has been replaced and the logged data has been downloaded to PC.
- Only use 3.6V 1/2AA lithium batteries. Check with your supplier that the battery you are ordering is 'press fit' and is not fitted with solder tags. Before replacing the battery, remove the EL-USB-CO from the PC.

Note:

Leaving the EL-USB-CO plugged into the USB port for longer than necessary will cause some of the battery capacity to be lost.



WARNING: Handle lithium batteries carefully, observe warnings on battery casing. Dispose of in accordance with local regulations.



LASCAR ELECTRONICS LTD.
MODULE HOUSE
WHITEPARISH
WILTSHIRE SP5 2SJ
UK
TEL: +44 (1794) 884567
FAX: +44 (1794) 884616
E-mail: sales@lascar.co.uk

LASCAR ELECTRONICS INC.
3750 West 26th Street
Erie
PA 16506
USA
TEL: +1 (814) 835 0621
FAX: +1 (814) 838 8141
E-mail: us-sales@lascarelectronics.com

LASCAR ELECTRONICS (HK) LIMITED
FLAT C, 5/FL., LUCKY FTY. BLDG.
63-65 HUNG TO ROAD
KWUN TONG KOWLOON
HONG KONG
TEL: +852 2797 3219
FAX: +852 2343 6187
E-mail: purchasing@lascar.com.hk

Specifications liable to change without prior warning

EL-USB-CO

Issue 3

05/2006

M.C.

Applies to EL-USB-CO/2



www.lascarelectronics.com