

SENSAPHONE Monitoring Sensor

WSG30 Wireless Sensors

WSG Wireless Dry Contact Sensor



Description

The WSG Wireless Dry Contact sensor is designed to work exclusively with the Sensaphone WSG30. This sensor includes a built-in radio transmitter and input terminals for connecting to any normally-open or normally closed output. (Use of this device with solid-state outputs is not recommended.) The sensor comes with two AA alkaline batteries which will power the sensor for up to two years. An optional plug-in power supply is also available. The batteries then become a backup if main AC power fails.

Specifications

- Package Contents**
- (1) WSG Wireless Dry Contact Sensor
 - (2) AA Alkaline batteries
 - (1) Mounting kit

Operating Temperature Range: 32° to 122°F (0° to 50°C)	Wireless Technology: ISM 2.4GHz, 100 mW (20dBm)
Operating Humidity Range: 0–95%	Housing: White plastic
Input Characteristics: 3MΩ To 3V	Size: 3.1” x 3.8” x 1.1” 7.9cm x 9.8cm x 2.85cm
Range: Up to 300’ (90m)	Compatibility: WSG30
Power Requirements: (2) AA Batteries / 5VDC Power Supply (Router Mode)	<i>*Specifications subject to change without notice</i>

WSG Wireless Dry Contact Sensor	FGD-WSG30-DRY
5V Power Supply	XFR-0041