

SENSAPHONE Monitoring Sensor

WSG30 Wireless Sensors

WSG Wireless Temperature Sensor



Description

The WSG Wireless Temperature sensor is designed to work exclusively with the Sensaphone WSG30. This sensor includes a built-in radio transmitter and temperature element for monitoring temperature wherever the device is installed. You can remove the internal temperature element and attach a remote temperature probe so that measurements can be made in a refrigerator, freezer or other harsh environment. The sensor comes with two AA alkaline batteries which will power the sensor for up to two years. An optional plug-in power supply is also available in which case the batteries become a backup if main AC power fails.

Specifications

- Package Contents**
- (1) WSG Wireless Temperature Sensor
 - (2) AA Alkaline batteries
 - (1) Mounting kit

Temperature Range:
32° to 122°F (0° to 50°C)
with External Probe:
-109° to 115°F (-85° to 57°C)

Sensor type:
2.8K Thermistor

Accuracy:
± 1.0°F (± 0.56°C)

Range:
Up to 300' (90m)

Power Requirements:
(2) AA Batteries / 5VDC Power Supply (Router Mode)

Wireless Technology:
ISM 2.4GHz, 100 mW (20dBm)

Housing:
White plastic

Size:
3.1" x 3.8" x 1.1"
7.9cm x 9.8cm x 2.85cm

Compatibility:
WSG30

**Specifications subject to change without notice*

WSG Wireless Temperature Sensor	FGD-WSG30-TMP
WSG Wireless Temperature Sensor w/ external probe	FGD-WSG30-TEX
5V Power Supply	XFR-0041