

SENSAPHONE Monitoring Sensor

WSG30 Wireless Sensors

WSG Wireless Humidity Sensor



Description

The WSG Wireless Humidity Sensor is designed to work exclusively with the Sensaphone WSG30. This sensor includes a built-in radio transmitter and humidity sensor element for monitoring humidity wherever the device is installed. The sensor comes with two AA alkaline batteries which will power the sensor for up to two years. An optional plug-in power supply is also available. The batteries then become a backup if main AC power fails..

- Package Contents**
- (1) WSG Wireless Humidity Sensor
 - (2) AA Alkaline batteries
 - (1) Mounting kit

Specifications

<p>Operating Temperature Range: 32° to 122°F (0° to 50°C)</p> <p>Operating Humidity Range: 0–100%</p> <p>Accuracy: ± 3% from 20-80% RH ± 5% otherwise</p> <p>Range: Up to 300' (90m)</p> <p>Power Requirements: (2) AA Batteries / 5VDC Power Supply (Router Mode)</p>	<p>Wireless Technology: ISM 2.4GHz, 100 mW (20dBm)</p> <p>Housing: White plastic</p> <p>Size: 3.1" x 3.8" x 1.1" 7.9cm x 9.8cm x 2.85cm</p> <p>Compatibility: WSG30</p> <p><i>*Specifications subject to change without notice</i></p>
---	--

WSG Wireless Humidity Sensor	FGD-WSG30-HUM
5V Power Supply	XFR-0041